

KITACO SHOCK ABSORBER

APPLICATION : GROM (06/75-02)
REMARK : FREE LENGTH 244mm
(SAME AS STOCK)

CODE : BLACK BODY (SPRING COLOR)
(BLUE) 520-1432110 / (RED) 520-1432120 / (YELLOW) 520-1432130

- Thank you for purchasing Kitaco product.
Read and understand the instruction before installing.

ATTENTION (MUST READ)

- Please ask authorized mechanic for assembling and setting. Ask a specialist at specialty shop if you do not understand the role of the surrounding parts.
- We are not responsible for violation of law or damages and accidents caused by assembling mistake and improper setting.
- After installation, handling stability has changed compared to stock one. Please ride safely.
- Refer to the manufacturer service manual when installation.
- Bolts and nuts may get loosen by engine vibration. Make sure not to loosen any bolts and nuts before driving.
- Do not modify the way which is not listed or it will cause damage and trouble. Metal/resin products get discolored/rust for ages as well as how to use. Please understand when using.

HOW TO INSTALL

If there is a hard degradation like a blem, fatigue and wear etc on the reuse parts, please change to new ones.

- 1) Stable the vehicle by using maintenance stand, etc.
- 2) Remove body cover, etc in need. (Refer to the service manual about removing / installing outer cowls.)
- 3) Remove stock rear shock, then install Kitaco one.

Tighten upper / lower mounting bolt (nut) with specified torque.

UPPER / LOWER BOLT : 44N m (4.5kgf m)

- 4) Adjust each parts and make sure not to loosen any parts before riding.

NON-STEP PRELOAD ADJUSTMENT

Loosen lock nut and adjust adjuster position to preload adjustment.

After adjustment, tighten lock nut with spanner.



OPTION PARTS	CODE
PIN SPANNER 150mm (Φ40~60)	
HOOK WRENCH (Φ32~75)	



3-8-13 NAGATA,
HIGASHI-OSAKA,
OSAKA, JAPAN
<https://www.kitaco.co.jp/>